

## **LabelWriter 300 and 400 Printer Drivers for Win. 98/ME/2000/XP**

This file includes all printer drivers for the 300 and 400 series LabelWriters. This executable will simply extract the drivers and save them on your system in the location you specify. Below are instructions for manually installing a LabelWriter to your computer.

### **Download and Installation Instructions:**

1. Download the file to your desktop
2. Go to your Desktop and double-click on the filename *300-400\_drivers.exe*.
3. The **WinZip Self-Extractor** window will appear
4. In the **Unzip to Folder** field, type **C:\lw**. This will create an empty folder where the new printer drivers will reside.
5. Click the **Unzip** button
6. Once you see the message saying that the 39 files unzipped successfully, close the WinZip Self-Extractor window
7. Be sure the printer is turned on and connected securely to the computer
8. Go to the **Printers** folder and run the **Add Printer Wizard**
9. Follow the on screen instructions until asked for driver location
10. Select **Specify Location** and navigate to the location of the new drivers, referenced above (Note: location is **c:\lw**)
11. Continue with the printer wizard instructions until complete
12. Launch your DYMO application and print a label

**Note:** DYMO testing for Windows NT stopped when Microsoft stopped supporting application development for it. Therefore you must download an older version of the software in order to obtain the print drivers. Please return to our Drivers and Downloads page and select *DYMO Software Application version 4.2.1 for Windows 95 and NT ONLY. DYMO LabelWriter 400 series printers are not compatible with Windows 95 and NT.*