

RHINO Drivers Version 1.1

Read Me — June 30, 2007

The RHINO Printer Drivers installer includes printer drivers for the RHINO 6000 and the RHINO 6500 label printers. RHINO printer drivers are available for both 32-bit and 64-bit systems. Make sure to download the correct version of the RHINO Drivers installer.

INSTALLATION NOTES

To install the printer drivers

1. Download the rhinodrivs-X86.msi or the rhinodrivs-X64.msi file.
2. Save it to your computer.
3. Double-click the installer file and follow the instructions.
4. Plug in your RHINO printer when instructed to do so by the installer.

Windows 2000

When connecting a RHINO printer to the USB port as prompted in the RHINO Drivers installer, you will see the New Hardware Found Wizard. When prompted for the location of the driver files, browse to the path where you installed the drivers. The default path is C:\Program Files\Rhino Drivers.

Windows Vista

When connecting a RHINO printer to the USB port as prompted in the RHINO Drivers installer, you will be asked to confirm whether to continue driver installation. Select **Locate and install driver software** to complete the installation.

PRINTING TO A RHINO PRINTER

When printing to a RHINO printer, make sure the tape size matches the tape cassette currently in the printer.

To change the tape size

1. From your application, select the RHINO printer as the current printer.
2. Set the paper size to match the tape size currently in the printer.